REPLACEMENT PARTS LIST

PART NO.	DESCRIPTION
035998	Body
040519	Neck
053694	Key
038901	Bridge Channel
019364	Bridge Spring, 9 coils
019281	Bridge Spring, 7 coils
019273	Bridge Spring, 6 coils
013136	Bridge Bar
013128	Bridge Bar
010454	Bridge Cover
034793	Pickguard
010389	Stringuide
016881	Stringuide Spacer
012344	Strap Button
034777	Lead Pickup
035584	Rhythm Pickup
016887	Pickup Cover
019505	Volume Control Knob
019497	Tone Control
015453	Volume Control (1 meg. lin. ped.)
015479	Tone Control (1 meg. audio)
015545	Capacitor (.03 MFD cer.)
021956	Phone Jack (2 cord open circ.)
019091	Sleeving
019547	Selector Switch Knob
017061	Lead Tone Selector Switch
013342	Rhythm Control Knob
015529	Rhythm Volume Control (1 min. lin.)
015511	Rhythm Tone Control (50K linear)
010470	Rhythm Control Mounting Bracket
017079	Pickup Selector Switch
020859	Capacitor (.02 MFD x 500V cer.)
010421	Tremolo Base Plate
010413	Tailpiece Plate
010439	Stiffner Plate
010447	Tailpiece Guide Plate
012393	Tremolo Receptacle
010397	Tremolo Lever
019463	Tremolo Lever Knob
024992	Spring Perch
019307	Tremolo Spring
012658	Lock Screw

REPLACEMENT PARTS LIST

PART NO.	DESCRIPTION
012377	Lock Button
010496	Pickup Shield
010512	Control Shield
010488	Rhythm Control Shield
040485	Pickguard Shield
012369	Bridge Receptacle
018630	Glazier Point
018648	Estucheon Pin
018556	Sponge Rubber Shim
045278	Instruction Manual

SCREWS, NUTS AND WASHERS

016188	Strap Button Screw (6 x 1" OH wood)
015693	String Length Adjustment Screw (4-40 x 1 3/8" RH machine)
040196	String Height Adjustment Screw (4-40 x 1/4" Set. Soc. OV. Pt.)
016089	String Height Adjustment Screw (4-40 x 5/16" Set. Soc. Ov. Pt.)
016097	Bridge Height Adjustment Screw (4-40 x 1/2" Set. Soc. Ov. Pt.)
015578	Pickguard Screw (4 x 1/2" OH sm.)
016329	Key Screw (3 x 3/8" RH wood)
016337	Stringuide Screw (3 x 5/8" RH phil.)
016295	Pickup Mounting Screw (3 x 1 RH wood)
015636	Neck Plate Screw (8 x 1 3/4" OH sm.)
015719	Rhythm Control Screw (4-40 x 1/4" OH machine)
015610	Outer Base Plate Screw (5 x 1" OH sm.)
015966	Upper Base Plate Screw (6-32 x 1 1/4" TH machine)
015891	Lower Base Plate Screw (8-32 x 1 1/4" TH machine)
015883	Tailpiece Plate Screw (8-32 x 1 1/4" FH machine)
016352	Control and Jack Nut (hex 3/8 x 32 thd)
022012	Lead Selector Switch Nut (hex 15/32 x 32 x 9/16)
012252	Neck Rod Nut
016436	Control and Inner Jack Washer (lock int. tooth 3/8)
031153	Outer Jack Washer (3/8 trim)
016469	Lead Selector Switch Washer (lock int. tooth 1/2")
016451	Rhythm Control Washer (int. tooth)
010504	Base Plate Washer (spring .171 id x .460 od)